

---

# Lg Washer Installation Guide

---

*Lg Washer Installation Guide*

*Downloaded from [turn-nyc-edge-ydmdp.louper.io](https://turn-nyc-edge-ydmdp.louper.io) by Walls & Marisa*

---

## INTRODUCTION: WHY PROPER INSTALLATION MATTERS FOR YOUR LG WASHER

---

Bringing home a new LG washer is an exciting moment. Whether you have invested in a front-load model with advanced steam technology or a top-loader with the innovative TurboWash feature, you are looking forward to cleaner clothes, lower energy bills, and a quieter laundry experience. However, before you can enjoy these benefits, you must complete one crucial step: proper installation. A correctly installed washing machine not only performs at its peak but also prevents costly water damage, excessive vibration, and premature wear on internal components. This comprehensive LG Washer Installation Guide will walk you through every stage of the process, from unpacking your appliance to running the first cycle. Whether you are a seasoned DIY enthusiast or a first-time homeowner, this guide provides the clarity and confidence you need to get your LG washer up and running safely and efficiently.

---

## PRE-INSTALLATION: WHAT YOU NEED BEFORE YOU

---

## BEGIN

---

Before you move the washer into position or reach for any tools, take time to prepare the installation site. Proper planning prevents most common installation headaches and ensures that your new appliance fits seamlessly into your laundry space.

## Site Selection and Clearance Requirements

Choose a location that is close to both water supply lines and a drain. The floor should be strong, level, and clean. Avoid installing your LG washer on carpet, as this can restrict airflow and cause vibrations. Leave at least one inch of clearance on the sides and rear of the machine. If you are installing the washer inside a closet or alcove, ensure there is adequate ventilation and that the door can be opened fully. For stacked installations with an LG dryer, verify that the stacking kit is compatible with your specific washer model and that the combined height fits your space.

# Tools and Materials You Will Need

Having the right tools on hand makes the installation process smooth and reduces frustration. Gather the following items before you begin:

- Adjustable wrench or pliers
- Screwdrivers (Phillips and flathead)
- Level (a standard carpenter's level is fine)
- Bucket or shallow pan
- Measuring tape
- Teflon tape for threaded connections
- Flashlight (for inspecting behind the machine)
- Soft cloth or towel

Your LG washer ships with the necessary hoses and installation hardware. Check the box or packaging material for these items before disposing of any boxes.

## Inspect the Delivery and the Appliance

Carefully inspect the outer packaging and the washer itself for signs of damage. If you notice dents, cracks, or punctures, document them with photographs and contact your retailer or LG

customer service before proceeding. Remove all tape, cardboard, and foam from the exterior. Open the washer door and check inside the drum for loose packing materials, the user manual, and any accessory bags. Do not discard the shipping bolts yet—you will need to remove them as part of the installation process.

---

### STEP 1: REMOVE THE SHIPPING BOLTS

---

This is one of the most important steps in any LG Washer Installation Guide. Shipping bolts secure the drum during transit to prevent damage. If you run the washer with these bolts still in place, you will cause severe internal damage to the suspension system and the drum itself. The noise and vibration will be extreme, and the repair cost will likely exceed the price of a new machine.

Locate the shipping bolts on the back of the washer. There are usually four bolts, each secured with a plastic spacer. Using a wrench or a socket set, loosen each bolt by turning it counterclockwise. Pull each bolt and its spacer straight out of the housing. Some models include plastic retainers that you must remove first. Store the shipping bolts in a safe place. If you move to a new home in the future, you will need to reinstall them to protect the washer during transport. Use the included hole caps to plug the openings left by the bolts.

---

### STEP 2: CONNECT THE WATER SUPPLY HOSES

---

Your LG washer requires both a hot and a cold water connection. The hoses provided with the machine are color-coded: red for hot and blue for cold. If you are replacing an old washer, inspect the

existing shut-off valves. If they are corroded or leaking, replace them before connecting the new hoses. This is also a good time to check that the water pressure is within the recommended range, typically between 20 and 120 psi.

## Attaching Hoses to the Washer

Wrap a few layers of Teflon tape clockwise around the threaded ends of the water supply hoses. This helps create a watertight seal. Hand-tighten the hose connections onto the corresponding inlet valves at the back of the washer. Use a wrench to tighten an additional quarter turn. Do not overtighten, as this can crack the plastic fittings. Next, connect the opposite ends of the hoses to your home water supply valves. Again, hand-tighten first, then give a slight boost with the wrench. Open both valves slowly and check for leaks at every connection point. Leave the valves open and keep an eye on them while you proceed.

---

### STEP 3: INSTALL THE DRAIN HOSE

---

Proper drainage is essential for your washer to function correctly. The drain hose is located at the back of the machine, usually secured with a clamp to a drain pump outlet. Remove the clamp and pull the hose free if it is bundled for shipping. Route the hose to your home drain system. You have three common options:

- **Standpipe:** Insert the hose into a dedicated laundry standpipe. The pipe should be between 18 and 96 inches

high. Secure the hose with a U-shaped bracket or zip tie to prevent it from slipping out during the drain cycle.

- **Laundry sink:** Hook the U-shaped end of the drain hose over the edge of a utility sink. Ensure the hose is not fully submerged in standing water, as siphoning can occur.
- **Floor drain:** If using a floor drain, you may need to raise the hose at least 24 inches above the floor to prevent water from siphoning back into the washer. Use the provided hose guide if your model includes one.

Avoid kinking or crushing the drain hose. Do not extend the hose beyond four feet, as this can restrict water flow and cause poor draining performance. If you need a longer hose, purchase an LG-approved extension kit.

---

### STEP 4: LEVEL THE WASHER

---

An unbalanced washer is noisy, shakes excessively, and can walk across your laundry room floor. Leveling your LG washer is a simple but critical step. Place your level on top of the washer, first side to side, then front to back. The bubble should be centered each time.

The front legs of the washer are adjustable. Use a screwdriver to turn the leveling feet clockwise to raise the corner or counterclockwise to lower it. Most LG washers also have lock nuts on the legs. Loosen the lock nut, adjust the foot, then retighten the nut snug against the base of the washer. Check the level again and repeat until the machine is stable. Tilt the washer gently from each corner to confirm that all four legs are making firm contact with the floor. If the washer rocks, adjust the

offending leg slightly. Once leveling is complete, rock the washer diagonally from corner to corner; there should be minimal movement.

---

## STEP 5: CHECK ELECTRICAL CONNECTIONS AND POWER UP

---

Your LG washer requires a dedicated 120-volt, 60-hertz AC outlet that is properly grounded. Never use an extension cord or a power strip, as these can overheat and cause a fire hazard. Plug the power cord into the outlet firmly. If the outlet is behind the washer, plug it in before sliding the machine into its final position. Some models have a power cord that is permanently attached; others allow you to swap between a plug and direct wiring. Consult your user manual for your specific model. Before proceeding, verify that the outlet is live by pressing the Power button on the control panel. The display should light up, and any indicator lights should appear.

---

## STEP 6: RUN THE INITIAL TEST CYCLE

---

Do not load clothes into the washer for its first cycle. Instead, run a test cycle to confirm that all connections are secure and that the machine functions properly. Open the hot and cold water supply valves fully. Add a small amount of detergent to the dispenser drawer—about one tablespoon is enough. Select a normal or cotton cycle, and choose the highest spin speed available. Press Start.

Let the washer fill, wash, drain, and spin. Watch for the following signs of proper operation:

- The drum fills with water and begins to tumble
- No water leaks from the hoses, the drain connection, or the detergent drawer
- The washer spins smoothly without excessive shaking or loud banging
- The drain pump removes water efficiently, and the drain hose does not overflow
- The cycle completes without error codes

If you notice any leaks, stop the cycle immediately, close the water valves, and address the issue. Leaks are almost always caused by loose hose connections, missing rubber washers inside the hoses, or improper drain hose routing. Once the test cycle finishes, inspect the floor area for any standing water. Wipe down the drum and the door gasket with a soft cloth. Your LG washer is now ready for regular use.

---

## COMMON MISTAKES TO AVOID DURING INSTALLATION

---

Even experienced homeowners can make errors when installing a new washing machine. Being aware of the most frequent pitfalls will help you sidestep them entirely.

- **Forgetting to remove the shipping bolts:** This is the most common and most damaging mistake. The washer will shake violently, walk across the floor, and sustain internal damage within minutes.
- **Using old water hoses:** Rubber hoses degrade over time. Use only the new hoses that came with your washer or

purchase high-quality stainless steel braided hoses for extra durability.

- **Overtightening connections:** Plastic inlet valves are easily cracked. Tighten until snug, then add a quarter turn. You do not need Herculean force.
- **Skipping the leveling step:** Even a floor that looks perfectly flat can cause imbalance. Always use a level. An unbalanced washer reduces cleaning performance and shortens the lifespan of bearings and suspension components.
- **Blocking the drain hose:** A kinked or blocked drain hose will cause water to back up into the drum, leaving your clothes soaking wet at the end of a cycle. Ensure the hose has a smooth, clear path.
- **Installing on a weak or uneven floor:** If your laundry room floor is made of wood joists, consider installing a rubber anti-vibration mat beneath the washer to reduce noise and movement. Avoid installing directly on carpet.

---

## MAINTENANCE TIPS AFTER INSTALLATION

---

Now that your LG washer is installed correctly, a few simple habits will keep it running smoothly for years. Clean the door gasket and the glass door opening monthly to prevent mold and mildew buildup. Wipe down the detergent drawer and clean out

any residual fabric softener or bleach. Once a month, run an empty cycle with a washing machine cleaner or a cup of white vinegar to remove mineral deposits and odors. Check and clean the drain pump filter every few months—your user manual will show you where it is located. Leave the washer door slightly open between uses to allow the interior to dry completely. Finally, inspect the water hoses every six months for bulging, cracking, or leaks. Replace them every three to five years as a preventative measure.

---

## CONCLUSION: ENJOY YOUR PERFECTLY INSTALLED LG WASHER

---

Following this LG Washer Installation Guide ensures that your new appliance will deliver the performance, efficiency, and reliability you expect from the LG brand. By taking the time to prepare your site, remove the shipping bolts, connect the hoses and drain correctly, and level the machine precisely, you have eliminated the most common causes of service calls and premature wear. Your first test cycle has confirmed that everything is working as designed. Now you can load your first full laundry basket with confidence, knowing that your washer is set up for optimal performance. A little upfront effort pays dividends in quieter operation, fewer repairs, and cleaner clothes cycle after cycle. Welcome to the world of effortless laundry with your new LG washer.