

# Electrical Engineering Formulas Cheat Sheet

Electrical Engineering Formulas Cheat Sheet

Downloaded from [turn-nyc-edge-vdmdp.louper.io](https://turn-nyc-edge-vdmdp.louper.io) by Kaiya & Diaz

## INTRODUCTION: WHY EVERY ENGINEER NEEDS A RELIABLE ELECTRICAL ENGINEERING FORMULAS CHEAT SHEET

Electrical engineering is a discipline built on precision, logic, and the consistent application of mathematical principles. Whether you are a student preparing for an exam, a practicing engineer troubleshooting a complex circuit, or a hobbyist designing your first PCB, the ability to recall and apply the right formula at the right time can mean the difference between a successful project and a frustrating failure. This is precisely where a well-organized **Electrical Engineering Formulas Cheat Sheet** becomes an indispensable tool. It serves not merely as a collection of equations, but as a mental map that connects fundamental laws with practical applications. In this comprehensive guide, we will walk through the most essential formulas across key domains of electrical engineering, explaining their significance and providing context so that you can use them with confidence. By the end of this article, you will have a thorough reference that feels like a natural extension of your own knowledge.

## FUNDAMENTAL LAWS GOVERNING ELECTRIC CIRCUITS

Every electrical engineering journey begins with understanding the foundational relationships between voltage, current, resistance, and power. These are the building blocks upon which all other concepts are built, and mastering them is non-negotiable. An effective **Electrical Engineering Formulas Cheat Sheet** must place these core equations at the forefront.

## Ohm's Law

Ohm's Law is the single most important relationship in electrical engineering. It states that the current flowing through a conductor between two points is directly proportional to the voltage across the two points and inversely proportional to the resistance. The formula is expressed as:

$$\mathbf{V = I \times R}$$

Where **V** is voltage in volts, **I** is current in amperes, and **R** is resistance in ohms. By rearranging this simple equation, you can solve for any unknown parameter: **I = V / R** and **R = V / I**. This triangle of relationships forms the basis for analyzing DC circuits, selecting components, and understanding load behavior.

## Power Calculations

Power, measured in watts, represents the rate at which energy is consumed or produced in a circuit. The fundamental power formula is intimately tied to Ohm's Law:

$$\mathbf{P = V \times I}$$

By substituting Ohm's Law, you can derive two additional forms that are extremely useful. Using **V = I x R**, you get **P = I² x R**. Using **I = V / R**, you get **P = V² / R**. Having all three variations on your **Electrical Engineering Formulas Cheat Sheet** allows you to choose the most efficient calculation based on the parameters you already know.

## DC CIRCUIT ANALYSIS FORMULAS

Direct current circuits are the simplest to analyze, but they require a solid grasp of series and parallel configurations. Engineers frequently combine these elements in complex networks, and a clear formula reference is vital for quick analysis.

## Series Circuits

In a series circuit, components are connected end-to-end, so the same current flows through each element. The total resistance is simply the sum of all individual resistances:

$$\mathbf{R_{total} = R_1 + R_2 + R_3 + \dots + R_n}$$

The voltage across the entire circuit is equal to the sum of voltage drops across each component. Conversely, the current is identical throughout the circuit. This additive behavior makes series circuits straightforward but also means that a single component failure can interrupt the entire path.

## Parallel Circuits

Parallel circuits provide multiple paths for current to flow. The total resistance in a parallel network is less than the smallest individual resistance. The formula for two resistors in parallel is:

$$\mathbf{R_{total} = (R_1 \times R_2) / (R_1 + R_2)}$$

For multiple resistors, the reciprocal formula is more practical:

$$\mathbf{1 / R_{total} = 1 / R_1 + 1 / R_2 + \dots + 1 / R_n}$$

Voltage is constant across all parallel branches, while the total current is the sum of currents in each branch. This configuration is widely used in household wiring and power distribution because it allows devices to operate independently.

## Kirchhoff's Laws

Kirchhoff's Current Law (KCL) states that the total current entering a junction must equal the total current leaving it. Mathematically:  $\sum I_{in} = \sum I_{out}$ . Kirchhoff's Voltage Law (KVL) asserts that the sum of all voltage drops around any closed loop in a circuit must equal zero:  $\sum V = 0$ . These two laws are indispensable for analyzing complex circuits that cannot be reduced to simple series or parallel combinations. They form the theoretical backbone for nodal and mesh analysis, which are standard techniques in circuit simulation software.

## AC CIRCUIT ANALYSIS FORMULAS

Alternating current introduces concepts such as frequency, phase, and reactance, which make circuit behavior more dynamic than in DC systems. A comprehensive **Electrical Engineering Formulas Cheat Sheet** must include the key equations for AC circuits, especially those involving reactive components.

## Impedance and Reactance

Impedance extends the concept of resistance to AC circuits by including the effects of capacitors and inductors. It is a complex quantity expressed as **Z = R + jX**, where **R** is resistance and **X** is reactance. Capacitive reactance is given by:

$$\mathbf{X_c = 1 / (2\pi fC)}$$

Inductive reactance is given by:

$$\mathbf{X_L = 2\pi fL}$$

In these formulas, **f** is frequency in hertz, **C** is capacitance in farads, and **L** is inductance in henries. Understanding reactance is crucial for designing filters, tuning circuits, and analyzing power factor correction.

## Power in AC Circuits

AC power is more complex than its DC counterpart because voltage and current may not be in phase. There are three types of power to consider. Real power (measured in watts) is given by:

$$\mathbf{P = V \times I \times \cos(\theta)}$$

Reactive power (measured in volt-amperes reactive, or VAR) is:

$$\mathbf{Q = V \times I \times \sin(\theta)}$$

Apparent power (measured in volt-amperes) is:

$$\mathbf{S = V \times I}$$

The power factor, **cos(θ)**, indicates how effectively electrical power is being used. A power factor close to 1 is desirable for efficiency, while a low power factor indicates that significant reactive power is cycling between source and load.

## Resonance in RLC Circuits

At the resonant frequency of an RLC circuit, the inductive and capacitive reactances cancel each other out, leaving only the resistive component. The resonant frequency is given by:

$$\mathbf{f_r = 1 / (2\pi\sqrt{LC})}$$

At resonance, the circuit exhibits maximum current in a series configuration and maximum impedance in a parallel configuration. This principle is exploited in radio tuners, oscillator circuits, and bandpass filters.

## POWER SYSTEMS AND ENERGY FORMULAS

The efficient generation, transmission, and distribution of electrical power depend on a set of core formulas that every engineer involved in power systems must internalize. These equations connect theoretical circuit analysis to real-world infrastructure.

## Three-Phase Power

Three-phase systems are the backbone of industrial and commercial power distribution. For a balanced system, the total real power is given by:

$$\mathbf{P_{3\phi} = \sqrt{3} \times V_L \times I_L \times \cos(\theta)}$$

Where **V<sub>L</sub>** is line-to-line voltage and **I<sub>L</sub>** is line current. This formula accounts for the phase displacement between the three waveforms, which allows for constant power delivery and more efficient use of conductors compared to single-phase systems.

## Energy Consumption

The total electrical energy consumed over a period of time is the product of power and time. The formula is straightforward:

$$\mathbf{E = P \times t}$$

Energy is typically measured in kilowatt-hours (kWh). For example, a 100-watt light bulb running for 10 hours consumes 1 kWh of energy. This simple calculation is essential for estimating operating costs, sizing battery banks, and evaluating the economic feasibility of energy projects.

## Efficiency and Losses

The efficiency of any electrical system or device is the ratio of useful output power to input power:

$$\mathbf{\eta = (P_{out} / P_{in}) \times 100\%}$$

Losses in transmission lines, transformers, and motors are often due to resistive heating. The power loss in a conductor is given by **P<sub>loss</sub> = I² x R**, known as copper loss. Understanding and minimizing these losses is a primary concern in power system design.

## ELECTROMAGNETIC FORMULAS

Electromagnetism is at the heart of motors, generators, transformers, and countless sensors. A reliable **Electrical Engineering Formulas Cheat Sheet** must include the fundamental equations that govern magnetic fields and induction.

## Ampere's Law and Magnetic Field Strength

Ampere's Law relates the integrated magnetic field around a closed loop to the electric current passing through the loop. For a long straight conductor, the magnetic field at a distance **r** from the conductor is:

$$\mathbf{B = (\mu_0 \times I) / (2\pi r)}$$

Where **μ<sub>0</sub>** is the permeability of free space. This formula is foundational for understanding how current-carrying wires generate magnetic fields and is applied in the design of inductors, electromagnets, and electric motors.

## Faraday's Law of Induction

Faraday's Law states that a changing magnetic field through a coil induces an electromotive force (EMF) in the coil. The magnitude of the induced voltage is:

$\epsilon = -N \times (d\Phi / dt)$

Where **N** is the number of turns in the coil and **dΦ / dt** is the rate of change of magnetic flux. The negative sign indicates that the induced EMF opposes the change in flux, which is Lenz's Law. This principle is the basis for transformers, generators, and inductive charging systems.

## Transformer Relationships

An ideal transformer relates primary and secondary voltages and currents by the turns ratio:

$V_s / V_p = N_s / N_p$  and  $I_s / I_p = N_p / N_s$

This allows voltage to be stepped up or down while conserving power (neglecting losses). The ability to efficiently change voltage levels is what makes AC power transmission economically viable over long distances.

---

### ELECTRONIC CIRCUIT FORMULAS

---

Electronics extends circuit theory into the realm of semiconductors, amplifiers, and digital logic. While the range of topics is vast, certain core formulas recur frequently and deserve a place on any comprehensive cheat sheet.

## Operational Amplifier Fundamentals

The operational amplifier, or op-amp, is a versatile building block in analog electronics. In an ideal inverting