

---

# How To Make A Sploof

---

Downloaded from [turn-nyc-edge-vdmdp.louper.io](https://turn-nyc-edge-vdmdp.louper.io) by  
Leon & Autumn

How To Make A Sploof

---

## INTRODUCTION

---

For many people who enjoy smoking or vaping, discretion is a top priority. Whether you live in an apartment with close neighbors, share a residence with non-smokers, or simply prefer to keep the aroma of your herbs to yourself, managing smoke odor can be a challenge. This is where the humble sploof comes into play. A sploof is a simple, effective device that filters the smoke you exhale, drastically reducing the smell. While you can buy expensive commercial filters, learning **how to make a sploof** at home is incredibly easy, cost-effective, and highly customizable. In this comprehensive guide, we will walk you through everything you need to know: from basic dryer sheet versions to advanced activated carbon designs. By the end, you will have the knowledge to create a sploof that fits your needs and helps you maintain a low profile.

---

## WHAT IS A SPOOF AND HOW DOES IT WORK?

---

Before diving into the construction, it is important to understand the science behind a sploof. At its core, a sploof is a tube or container filled with materials that absorb, trap, or neutralize smoke particles and odors. When you exhale through the device, the smoke passes through multiple layers of filtration media, leaving the air that emerges considerably cleaner and less pungent.

The most common filtration media include:

- **Activated carbon** – Highly porous carbon that chemically bonds with odor molecules.
- **Dryer sheets** – Scented fabric softener sheets that mask and absorb some odors.
- **Cotton balls or fabric** – Provide physical trapping of larger particles.
- **Rubber bands or tape** – Secure the layers and create an airtight seal.

The effectiveness of your sploof depends largely on the quality of the materials and how well you seal the device. While a simple dryer sheet sploof can mask smoke smell for a short time, an activated carbon version will neutralize odors much more thoroughly. Understanding these basics will help you choose the right method when you learn **how to make a sploof** that meets your specific needs.

---

## MATERIALS NEEDED FOR A DIY SPOOF

---

One of the great things about making a sploof is that you probably already have most of the supplies at home. Here is a list of common items you can use, depending on which version you decide to build:

# Basic Sploof (Dryer Sheet Only)

- An empty toilet paper roll or paper towel roll (cardboard tube)
- 2-3 unscented or scented dryer sheets
- A rubber band or piece of tape
- Optional: a second rubber band for the mouthpiece end

# Advanced Sploof (Activated Carbon)

- An empty toilet paper or paper towel roll
- Activated carbon (available at pet stores, aquarium shops, or online)
- Cotton balls or a small piece of cotton fabric
- A coffee filter or thin cloth to hold the carbon
- Rubber bands and tape
- Scissors
- Optional: a plastic bottle (if you want a reusable container)

Gathering your materials ahead of time will make the process smooth and quick. Remember, the goal when learning **how to make a sploof** is to create an airtight pathway that forces the smoke through the filtering medium.

## STEP-BY-STEP GUIDE TO MAKING A BASIC SPLOOF

This simple version works in a pinch and

is great for masking smoke odor temporarily. Follow these steps:

1. **Prepare the tube.** Take an empty toilet paper roll or cut a paper towel roll to a comfortable length (about 4-5 inches).
2. **Attach the first dryer sheet.** Place one dryer sheet over one end of the tube and secure it tightly with a rubber band. Make sure the sheet is stretched flat and does not have gaps.
3. **Add a second layer.** Place another dryer sheet over the first one, but this time, fold it slightly so it creates a pocket. Secure it with another rubber band. This double layer traps more particles.
4. **Optional: freshen the other end.** You can also attach a dryer sheet to the mouthpiece end using a rubber band, but be careful not to obstruct your airflow too much.
5. **Test your sploof.** Lightly exhale a small amount of smoke through the device. You should see the smoke filtering through the sheets and notice a significant reduction in odor. If the airflow feels too restricted, loosen the rubber bands slightly.

That is it! You have created your first sploof in under two minutes. However, if you want a more effective solution that truly eliminates rather than masks odors, read on for the advanced method.

## HOW TO MAKE AN ADVANCED SPLOOF WITH ACTIVATED CARBON

Activated carbon is the gold standard for odor filtration because its porous structure adsorbs chemicals rather than just covering them up. Here is a detailed

guide for a powerful DIY splroof that rivals commercial products:

1. **Choose your container.** A paper towel roll works best because it is longer and can hold more carbon. Alternatively, you can use a plastic bottle (cut the bottom off and flip it). Clean and dry the container thoroughly.
2. **Create a base filter.** Cut a small piece of coffee filter or thin cotton fabric larger than the diameter of the tube. Place it over one end and secure it with a rubber band. This will keep the carbon from falling out.
3. **Add a layer of cotton.** Insert a few cotton balls into the tube from the open end, pushing them down against the base filter. This prevents carbon dust from escaping.
4. **Fill with activated carbon.** Carefully pour activated carbon into the tube until it is about 1 to 2 inches deep. You can use a funnel or a folded piece of paper to avoid spills. Tamp it down gently but do not pack it too tightly – you need airflow.
5. **Add another cotton layer.** Place more cotton balls on top of the carbon to hold it in place. The cotton also acts as a pre-filter for larger smoke particles.
6. **Seal the top.** Use a coffee filter or fabric over the open end, secured with a rubber band. You can also use a dryer sheet on top for a pleasant scent, but remember that the carbon is doing the heavy lifting.
7. **Final assembly.** Ensure both ends are securely fastened. You can wrap tape around the rubber

bands to make the seal even tighter. The mouthpiece end (where you exhale) should be the end without the carbon – typically the base filter side. Exhale gently to test. You should feel very mild resistance.

This advanced **how to make a splroof** method can last for dozens of uses before the carbon becomes saturated. When the smell starts to break through, simply replace the carbon and cotton.

---

### TIPS FOR USING AND MAINTAINING YOUR SPLROOF

---

Building a splroof is only half the battle. To get the most out of your device, follow these practical tips:

- **Exhale slowly and steadily.** Rushing forces smoke through too quickly, reducing contact time with the filter. Slow exhales improve absorption.
- **Keep your splroof dry.** Moisture reduces the effectiveness of activated carbon. Store it in a dry place and avoid getting it wet.
- **Replace materials regularly.** For basic splroofs, change the dryer sheets every few sessions. For carbon versions, replace the carbon when you notice odors escaping.
- **Use a secondary filter.** If you are in a very sensitive environment, consider exhaling into a splroof that leads into a sealed container (like a plastic bottle) with more carbon – but that is an advanced setup.
- **Pair with other odor control.** A splroof works best alongside good ventilation, incense, or air purifiers for maximum discretion.

**ALTERNATIVES TO THE** quick-dry sheet adds the life of your sploof and ensures you always have reliable odor control. When you teach a friend **how to make a sploof**, share these tips so they get the best results.

### COMMON MISTAKES TO AVOID

Even a simple project like making a sploof can go wrong if you overlook key details. Here are pitfalls to steer clear of:

- **Overstuffing the tube.** While you want good filtration, packing too many materials creates excessive resistance. You should be able to exhale without puffing your cheeks.
- **Using wet or damp materials.** Wet dryer sheets or moist carbon lose their ability to trap odors. Always use dry, fresh supplies.
- **Poor sealing.** If there are gaps around the rubber bands or tape, smoke will leak out unfiltered. Test by blowing gently while holding the sploof under a light – you can see smoke escape.
- **Not changing the filter often enough.** A saturated sploof becomes ineffective and can even release trapped odors back into the air. Listen to your nose – if you can smell smoke after using it, replace the media.
- **Using scented products to cover up.** While a pleasant scent is nice, relying solely on perfume can backfire. The goal is to eliminate, not mask. Activated carbon is superior.

By avoiding these errors, you will master **how to make a sploof** that works reliably every time.

### TRADITIONAL SPLOOF

If you are not into DIY, or you want something more durable, consider these alternatives:

- **Commercial sploofs like Smokebuddy.** These are plastic, washable devices filled with activated carbon. They are compact and effective, but more expensive than homemade versions.
- **Electric air purifiers.** Small portable units can be placed near your smoking area, but they are not as discreet for on-the-go use.
- **Homemade bottle sploofs.** Some people use a 2-liter plastic bottle cut in half, filled with carbon and fabric, and taped back together. This allows for a larger filter and longer lifespan.
- **Snap filters for pipes.** Some smoking accessories have built-in carbon filters that reduce smell at the source.

Each option has pros and cons, but the DIY approach remains the most accessible and customizable. The knowledge of **how to make a sploof** empowers you to control the materials and cost.

### CONCLUSION

Learning how to make a sploof is a simple yet valuable skill for anyone seeking discretion. Whether you opt for the quick dryer sheet version or invest a few minutes in an activated carbon build, the result is a portable, effective odor-reduction tool that costs pennies to produce. Remember to prioritize good seals, dry materials, and regular

replacement to keep your sploof performing at its best. With this guide, you now have everything you need to create a sploof that suits your style and environment. So gather your supplies, follow the steps, and enjoy a more discreet experience. Happy crafting!