

---

# Rigid Frame Formulas

---

*Rigid Frame Formulas*

Downloaded from [turn-nyc-edge-ydmdp.louper.io](https://turn-nyc-edge-ydmdp.louper.io) by *Arias & Bowers*

---

## INTRODUCTION TO RIGID FRAME FORMULAS IN STRUCTURAL ENGINEERING

---

In the world of structural engineering, few concepts are as fundamental as the behavior of rigid frames. These structural systems, which consist of beams and columns connected by moment-resisting joints, form the backbone of countless buildings, bridges, and industrial structures. Understanding the formulas that govern their behavior is not merely an academic exercise but a practical necessity for any engineer involved in design, analysis, or construction. Rigid frame formulas provide the mathematical tools needed to predict how a structure will respond to various loads, ensuring safety, serviceability, and economic efficiency. This article delves into the core principles, essential formulas, and practical applications of rigid frame analysis, offering a comprehensive guide for engineers and students alike.

---

## WHAT ARE RIGID FRAMES AND WHY DO THEY MATTER?

---

A rigid frame, also known as a moment-resisting frame, is a

structural system in which beams and columns are connected by joints that can resist bending moments. Unlike pin-connected frames, where joints are free to rotate, rigid joints maintain the angle between connected members under load, transferring both shear forces and bending moments. This characteristic gives rigid frames their inherent stability and ability to withstand lateral loads such as wind and seismic forces.

The significance of rigid frame formulas lies in their ability to quantify this behavior. Without these formulas, engineers would have to rely on overly simplistic approximations or time-consuming iterative methods. Rigid frame formulas allow for the calculation of key parameters—such as bending moments, shear forces, axial forces, and deflections—with accuracy and efficiency. They form the foundation for designing safe and economical structures, from high-rise buildings and long-span bridges to industrial warehouses and offshore platforms.

---

## FUNDAMENTAL PRINCIPLES BEHIND RIGID FRAME FORMULAS

---

Before diving into specific formulas, it is essential to understand the underlying principles. Rigid frame analysis is rooted in three fundamental concepts: equilibrium, compatibility, and constitutive relationships.

# Equilibrium

Every structure must satisfy the conditions of static equilibrium. This means the sum of all forces and moments acting on any part of the frame must be zero. For a rigid frame, this involves balancing horizontal forces, vertical forces, and rotational moments at every joint and across the entire system. Equilibrium equations form the first step in any analysis, providing the basic constraints that the structure must meet.

# Compatibility

Compatibility refers to the requirement that deformations within the frame must be consistent. In a rigid frame, the rotations and deflections of connected members must match at the joints. This means the slope and displacement of a beam at a joint must equal those of the column at the same joint. Compatibility conditions ensure that the structure remains continuous and that no gaps or overlaps develop under load.

# Constitutive Relationships

These relationships connect stresses and strains in the material, typically through Hooke's Law for linear elastic behavior. For steel or concrete frames, the modulus of elasticity and moment of inertia are key parameters that influence how a member bends and deforms. Rigid frame formulas incorporate these material properties to convert applied loads into internal forces and

displacements.

---

## KEY RIGID FRAME FORMULAS EVERY ENGINEER SHOULD KNOW

---

While many specialized formulas exist for particular frame configurations, certain core expressions form the basis of most analyses. Below are some of the most important rigid frame formulas, along with explanations of their application.

## Slope-Deflection Equations

The slope-deflection method is one of the most powerful tools for analyzing statically indeterminate rigid frames. The fundamental slope-deflection equation for a prismatic beam segment is:

$$M_{AB} = (2EI / L) * (2\theta_A + \theta_B - 3\psi) + FEM_{AB}$$

In this formula,  $M_{AB}$  is the moment at end A of member AB, E is the modulus of elasticity, I is the moment of inertia, L is the length of the member,  $\theta_A$  and  $\theta_B$  are the rotations at ends A and B,  $\psi$  is the chord rotation (relative displacement divided by length), and  $FEM_{AB}$  is the fixed-end moment at A due to applied loads. This equation elegantly captures the relationship between joint rotations, member deformations, and internal moments.

The slope-deflection formulas are particularly valuable because they can be applied to any rigid frame, regardless of its geometry or loading conditions. By writing these equations for every member and solving the system simultaneously, engineers can determine all unknown rotations and displacements.

# Moment Distribution Method (Hardy Cross Method)

Developed by Professor Hardy Cross in the 1930s, the moment distribution method is an iterative technique that avoids solving large systems of equations. The key formulas in this method involve distribution factors and carry-over factors.

**Distribution Factor (DF) at a joint for a given member =**  
 $(K_{\text{member}}) / (\Sigma K_{\text{all members at joint}})$

Where  $K = I / L$  is the stiffness factor of the member. The distribution factor represents the proportion of an unbalanced moment that is distributed to a particular member.

**Carry-Over Factor (COF) = 0.5 for prismatic members**

When a moment is applied at one end of a prismatic member, half of that moment is carried over to the opposite end. This carry-over factor is a direct consequence of the slope-deflection equations and is fundamental to the moment distribution process.

## Fixed-End Moment

## Formulas

Fixed-end moments are the moments that develop at the ends of a member when both ends are fully restrained against rotation. These are used as starting points in both slope-deflection and moment distribution methods. Common fixed-end moment formulas include:

- **Uniformly distributed load (w) on a span of length L:**  
 $FEM = wL^2 / 12$  (at both ends, with sign conventions)
- **Concentrated load (P) at midspan:**  $FEM = PL / 8$
- **Concentrated load (P) at a distance a from left end and b from right end:**  $FEM_{\text{left}} = Pab^2 / L^2$ ,  $FEM_{\text{right}} = Pa^2b / L^2$

These formulas are derived from basic beam theory and are widely available in engineering handbooks. They save significant time by providing ready-made expressions for common loading conditions.

## Portal Frame Formulas for Lateral Loads

For rigid frames subjected to lateral loads (wind or earthquake), simplified portal frame formulas are often used in preliminary design. The portal method assumes that points of inflection occur at mid-heights of columns and mid-spans of beams. Based on this

assumption, the shear force in each column can be determined by distributing the total lateral load in proportion to the column stiffnesses.

**Shear in a column =  $(K_{\text{column}} / \Sigma K_{\text{columns}}) * \text{Total lateral force}$**

This simple formula allows engineers to quickly estimate member forces and moments for initial sizing, though more rigorous methods are needed for final design.

---

### ADVANCED RIGID FRAME FORMULAS FOR COMPLEX STRUCTURES

---

While the above formulas cover many common scenarios, modern structures often require more sophisticated approaches. Below are some advanced rigid frame formulas used in specialized contexts.

## Matrix Stiffness Method

The matrix stiffness method, also known as the direct stiffness method, is the foundation of most structural analysis software. The fundamental formula is:

$$\{F\} = [K] * \{D\}$$

Where  $\{F\}$  is the vector of applied forces,  $[K]$  is the global stiffness matrix of the frame, and  $\{D\}$  is the vector of unknown displacements. The stiffness matrix is assembled from individual member stiffness matrices, which are derived from the slope-deflection equations. This formula is the basis for finite element analysis of rigid frames and can handle arbitrary geometry,

loading, and support conditions.

## Second-Order Effects (P-Δ and P-δ Analysis)

For slender frames or those subjected to high axial loads, second-order effects become significant. The P-Δ effect considers the additional moment caused by the axial load acting through the lateral displacement of the story. The P-δ effect considers the additional moment within a member due to its deflected shape. Rigid frame formulas for second-order analysis often take the form of amplification factors:

$$M_{\text{design}} = M_{\text{first-order}} * (1 / (1 - P / P_{\text{cr}}))$$

Where  $P$  is the axial load and  $P_{\text{cr}}$  is the critical buckling load of the frame. This amplification factor accounts for the destabilizing effect of axial loads on the frame stiffness.

---

### PRACTICAL APPLICATIONS OF RIGID FRAME FORMULAS

---

Understanding rigid frame formulas is essential for a wide range of practical engineering tasks. Below are some real-world applications where these formulas play a critical role.

## Building Design

In multi-story buildings, rigid frames resist both gravity and lateral loads. Engineers use rigid frame formulas to determine the size and spacing of beams and columns, ensuring that deflections and drift are within acceptable limits. For example, in a 10-story office building, the moment distribution method might be used to analyze a typical floor frame under dead and live loads, while the portal method provides initial estimates for wind loads.

## Bridge Engineering

Rigid frames are common in bridge construction, particularly in rigid-frame bridges where the deck and piers are monolithic. Rigid frame formulas help engineers calculate the moments and shears at the deck-pier connection, which is critical for designing reinforcement and ensuring durability. The slope-deflection equations are especially useful for analyzing continuous spans with varying stiffness.

## Industrial Structures

Industrial buildings, such as warehouses and manufacturing plants, often use rigid frames to create large open spaces. These structures must support heavy equipment, overhead cranes, and dynamic loads. Rigid frame formulas enable engineers to design frames that are both strong and economical, optimizing the balance between material cost and structural performance.

---

### COMMON PITFALLS AND HOW TO AVOID THEM

---

Even experienced engineers can make mistakes when applying rigid frame formulas. Below are some common pitfalls and tips for avoiding them.

## Incorrect Sign Conventions

Rigid frame formulas are highly sensitive to sign conventions. A moment that is positive in one convention may be negative in another, leading to errors in the final results. Always follow a consistent sign convention throughout the analysis, and clearly document which convention is being used.

## Overlooking Axial Deformations

In many rigid frame formulas, axial deformations of members are neglected. While this is acceptable for most frames where bending dominates, it can lead to significant errors in frames with slender columns or high axial loads. When axial deformations matter, use the matrix stiffness method that includes axial degrees of freedom.

# Misapplication of Fixed-End Moments

Fixed-end moment formulas apply only to members with both ends fully fixed against rotation. If a member has a pin or roller support at one end, the fixed-end moments must be adjusted. Using standard FEM formulas without considering the actual support conditions is a common source of error.

# Ignoring Second-Order Effects

For tall or slender frames, first-order analysis may not be sufficient. Ignoring  $P-\Delta$  and  $P-\delta$  effects can lead to an

underestimate of moments and deflections, potentially compromising the safety of the structure. Always check whether second-order effects are significant and use appropriate amplification formulas if needed.

---

## TOOLS AND SOFTWARE FOR USING RIGID FRAME FORMULAS

---

While many engineers still perform hand calculations for simple frames, modern software has made rigid frame analysis faster and more accurate. Popular tools include:

- **MATLAB and Octave:** Excellent for implementing the matrix stiffness method and customizing rigid frame formulas for specific problems.
- **SAP2000 and ETABS:** Professional structural analysis software with built-in rigid frame elements, capable of both first-order and second-order analysis.
- **STAAD.Pro:** Widely used for structural design, with comprehensive rigid frame analysis capabilities and code